



UG434: Silicon Labs *Bluetooth*® C Application Developer's Guide for SDK v9.x and Higher



This version of UG434 has been deprecated.

For the latest version, see docs.silabs.com.

This document is an essential reference for everybody developing C-based applications for the Silicon Labs Wireless Gecko products using the Silicon Labs Bluetooth stack. The guide covers the Bluetooth stack architecture, application development flow, usage, and limitations of the MCU core and peripherals, stack configuration options, and stack resource usage. This version applies to the Silicon Labs Bluetooth Software Development Kit (SDK) version 9.x and higher.

The purpose of the document is to capture and fill in the blanks between the Bluetooth Stack API reference, Simplicity SDK API reference, and Wireless Gecko reference manuals, when developing Bluetooth applications for the Wireless Geckos. This document exposes details that will help developers make the most out of the available hardware resources.

KEY POINTS

- Project structure and development flow
- Bluetooth stack and Wireless Gecko configuration
- Interrupt handling
- Event and sleep management
- Resource usage and available resources

Table of Contents

| | |
|---|-----------|
| 1. Introduction | 4 |
| 1.1 About this Version | 4 |
| 1.2 Prerequisites | 4 |
| 2. Application Development Flow. | 5 |
| 2.1 Application Build Flow | 6 |
| 3. Project Structure | 7 |
| 3.1 Bluetooth Files | 7 |
| 3.2 GATT Database | 8 |
| 3.3 Device Firmware Upgrade | 8 |
| 3.4 NCP Applications | 8 |
| 3.5 RTOS Support | 9 |
| 3.6 Multiprotocol Support | 9 |
| 3.7 Platform Components | 9 |
| 4. Configuring the Bluetooth Stack and a Wireless Gecko Device | 10 |
| 4.1 Wireless Gecko MCU and Peripherals Configuration | 10 |
| 4.1.1 Bluetooth Clocks | 10 |
| 4.1.2 DC-DC Configuration | 11 |
| 4.1.3 LNA | 11 |
| 4.1.4 PTI | 11 |
| 4.1.5 Transmit Power | 12 |
| 4.1.6 Wi-Fi coexistence | 12 |
| 4.1.7 Mbedtls | 12 |
| 4.2 Bluetooth Stack Configuration | 12 |
| 4.2.1 Bluetooth On-Demand Start | 13 |
| 4.2.2 Bluetooth Buffer Memory | 13 |
| 4.2.3 Number of Connections | 13 |
| 4.2.4 Software Timers | 13 |
| 4.2.5 TX Power and RF Path. | 14 |
| 4.2.6 Security Manager | 14 |
| 4.2.7 Adaptive Frequency Hopping. | 15 |
| 4.2.8 Even Connection Distribution Algorithm | 15 |
| 4.2.9 Multiprotocol Priority Configuration | 16 |
| 4.2.10 Sleep | 16 |
| 4.2.11 PA | 16 |
| 4.3 OTA Configuration. | 16 |
| 4.4 Radio Co-Processor Mode | 17 |
| 5. Bluetooth Stack Event Handling | 18 |
| 5.1 Commands from Multiple Tasks | 18 |
| 6. Interrupts | 19 |

| | |
|--|------------|
| 6.1 External Event | .19 |
| 6.2 Priorities | .20 |
| 7. Wireless Gecko Resources | 21 |
| 7.1 Flash | .22 |
| 7.1.1 Optimizing Flash Usage | .23 |
| 7.1.2 Bluetooth Bonding Database | .23 |
| 7.2 Linking. | .23 |
| 7.3 RAM | .24 |
| 7.3.1 Bluetooth Stack | .24 |
| 7.3.2 Bluetooth Object Pools | .24 |
| 7.3.3 Bluetooth Buffer Memory | .24 |
| 7.3.4 Bluetooth GATT Database | .24 |
| 7.3.5 Call Stack | .25 |
| 7.3.6 Heap memory | .25 |
| 8. Application ELF-file. | 26 |
| 9. Documentation | .28 |

1. Introduction

This document is a C developer's guide for the Silicon Labs Bluetooth stack. It covers various angles of development, and is an important reference to everyone developing in C for Wireless Gecko products that are running the Bluetooth stack.

The document covers the following topics:

- Section [2. Application Development Flow](#) discusses the application development flow.
- Section [3. Project Structure](#) reviews project structure.
- Section [4. Configuring the Bluetooth Stack and a Wireless Gecko Device](#) explains the project include libraries and the actual Wireless Gecko configuration in the application code.
- Section [5. Bluetooth Stack Event Handling](#) is an important piece for everyone developing with the Silicon Labs Bluetooth stack, as it explains how the application runs in sync with the stack in an event-based architecture.
- Section [6. Interrupts](#) and section [7. Wireless Gecko Resources](#) touch on the topics of peripherals and the chipset resources, covering what is reserved for the stack usage, how interrupts should be handled, and the stack's memory footprint and available memory for the application.

1.1 About this Version

The current version of Silicon Labs' Bluetooth SDK is 9.x.

Currently supported compilers are:

- GCC 12.2.1
- IAR 9.40.1

1.2 Prerequisites

This document assumes the current version of Silicon Labs' Bluetooth SDK has been properly installed to the development machine (Windows, MAC OSX, or Linux), and that the reader is familiar with the quick start guides and with the SDK's examples. Also, the reader should have a basic understanding of Bluetooth technology. For more information, see *UG103.14: Bluetooth Technology Fundamentals*.

For instructions on getting started using example applications in Silicon Labs Simplicity Studio development environment, see *QSG169: Bluetooth® SDK v3.x Quick Start Guide*.

2. Application Development Flow

The following figure describes the high-level firmware structure. The developer creates an application on top of the stack, which Silicon Labs provides as a precompiled object-file, enabling the Bluetooth connectivity for the end-device.




Figure 2.1. Bluetooth Stack Architecture Block Diagram

The Bluetooth stack contains following blocks.

- **Bootloader**—The Gecko Bootloader is not part of the stack but is provided with the Bluetooth SDK. See *UG266: Gecko Bootloader User Guide* and *AN1086: Using the Gecko Bootloader with Silicon Labs Bluetooth Applications* for more information. For information on bootloading in general, see *UG103.06: Bootloading Fundamentals*.
- **Bluetooth stack**—Bluetooth functionality consisting of link layer, generic access profile, security manager, attribute protocol, and generic attribute profile.
- **Bluetooth AppLoader**—An application that starts after the bootloader. It checks if the user application is valid and, if it is, AppLoader starts the application. If the application image is not valid, AppLoader starts the OTA process to try to receive a valid application image. This requires using the Gecko Bootloader.

2.1 Application Build Flow




Figure 2.2. Bluetooth Project Build Flow

Building a project starts by defining the Bluetooth services and characteristics (GATT definitions) and by writing the application source code from Silicon Labs-provided examples or an empty project template, as described in *QSG169: Bluetooth® SDK v3.x Quick Start Guide*.

There are two ways to define Bluetooth services and characteristics. The first option is the Visual GATT Editor GUI in Simplicity Studio. This is a graphical tool for designing the GATT and for generating *gatt_db.c* and *gatt_db.h*. Additionally, it can import *.xml* GATT definition files. The Visual GATT Editor is the default tool for GATT definition and generation in Simplicity Studio projects.

The second option is to create an *.xml* according to the *UG118: Blue Gecko Bluetooth® Profile Toolkit Developer's Guide* and then use the BGBuild tool as a pre-compilation step to convert the GATT definition file into *.c* and *.h*. This method is used in IAR Embedded Workbench projects.

Compiling the project generates an object file, which is then linked with the pre-compiled libraries provided in the SDK. The output of the linking is a flash image that can be programmed to the supported Wireless Gecko devices.

3. Project Structure

This section explains the application project structure and the mandatory and optional resources that must be included in the project.

3.1 Bluetooth Files

Library Files

The Bluetooth stack is provided in multiple libraries. The Silicon Labs Configurator (SLC) tool adds the necessary libraries to the application project automatically.

RAIL

The Bluetooth stack uses RAIL to access the radio and RAIL libraries needs to be linked with Bluetooth stack. RAIL has separate libraries for each device family and for single- and multi-protocol environments. RAIL libraries are provided in the Simplicity SDK Suite. For more information refer to *UG103.13: RAIL Fundamentals* and other RAIL documentation.

Note: To ensure regulatory compliance of the radio module, the Bluetooth stack for the radio module needs to be linked together with the RAIL library and the configuration library for the radio module. These are `librail_module_<soc family><compiler>_release.a` and `librail_config<modulename>.a`.

EMLIB and EMDRV

The Bluetooth stack uses EMLIB and EMDRV libraries to access EFR32 hardware. EMLIB and EMDRV peripheral libraries are provided in source code and they must be included in the project. EMLIB and EMDRV are part of the Simplicity SDK Suite. For more details on EMLIB and EMDRV, see platform EMDRV documentation and EMLIB documentation on <https://docs.silabs.com/>.

MBED TLS

The Bluetooth stack uses the MbedTLS library for cryptographic operations. The MbedTLS library is provided in source code and must be included in the project. MbedTLS is part of the Simplicity SDK Suite. For more details, refer to the [MbedTLS documentation](#).

Sleep Timer

Sleep Timer is a platform component providing software timers, timekeeping, and date functionality. The Bluetooth stack uses it for internal event scheduling, and it must be included in the project. See [platform sleeptimer documentation](#).

Note that Sleep Timer callbacks are called from the interrupt context. BGAPI functions cannot be called from the callback. Instead, the application should implement the timer task handling in the application main loop. Several simple timer components in the SDK, for example, `simple_timer` and `simple_timer_micriumos`, implement helper functionality that also allows calling BGAPI command from its callback.

Power Manager

Power Manager is a platform component that manages the system's energy modes. Its main purpose is to transition the system to a low energy mode when the processor has nothing to execute. See the reference for your MCU on <https://docs.silabs.com/> under Modules>Platform Services>Power Manager.

Header Files

`sl_bt_version.h`

This file contains the Bluetooth stack version.

API Header Files

These files define the Bluetooth stack API.

These files serve two purposes:

1. They contain the actual Bluetooth stack API and the commands and events for the stack.
2. They provide a configuration and event management API to the Bluetooth stack.

sl_bt_types.h

sl_bt_stack_init.h

sl_bt_api.h

sl_bgapi.h

These files contain the Bluetooth stack API and the commands and events for the stack, and a configuration API for the Bluetooth stack.

sl_bt_ncp_host_api.c, sl_bt_ncp_host.c, sl_bt_ncp_host.h and sl_bt_internal.h

These files are used when developing applications for an external host. They provide the API definitions and adaptation layer between the host application and the BGAPI serial protocol.

3.2 GATT Database

The GATT (Generic Attribute Profile) database is a standardized way of describing the Bluetooth profiles, services, and characteristics of a Bluetooth device. The Silicon Labs' Bluetooth SDK provides two ways to define the GATT database:

- A static GATT database can be defined in compile time with the appropriate tools provided by the Bluetooth SDK, or can be written in XML and passed to the BGBuild tool as a pre-build task. In this case, the database structure is stored in the ROM, which means faster start-up time and lower memory usage.
- A dynamic GATT database can be defined in runtime with the appropriate BGAPI commands using the `bluetooth_feature_dynamic_gattdb` component. In this case, the database structure is stored in the RAM, which makes it more flexible. This is recommended in the NCP use case to avoid re-building the target code that runs on the Wireless Gecko.

You can also combine these two methods. For more information on how to create GATT databases and the syntax, refer to *UG118: Blue Gecko Bluetooth® Smart Profile Toolkit Developer's Guide*.

gatt_db.c and gatt_db.h

The `gatt_db.c` file defines the GATT database structure and content, and is auto-generated by BGBuild or by the Visual GATT Editor. The `gatt_db.h` file includes this database and the handles of local characteristics and services. Type definitions of GATT are automatically included from `bg_gatt_db_def.h` to `gatt_db.h`.

When a dynamic GATT database is used, the handles of a local characteristic or service may change if the attribute table is updated at run time. Therefore, it is not recommended to use the constants in `gatt_db.h` unless absolutely certain that the handle values of characteristics and services are not affected by the dynamic GATT database update.

3.3 Device Firmware Upgrade

Device Firmware Upgrade (DFU) is the process of upgrading the application either over a serial link or over-the-air (OTA). In both cases the application needs to add the following file to enable the support for DFU.

application_properties.c

This file includes the application properties struct that contains information about the application image, such as type, version, and security. The struct is defined in `application_properties.h` in the Gecko Bootloader API. A pre-generated file is included in Simplicity Studio projects, which can be modified to include application-specific properties. The application properties can be accessed using the Gecko Bootloader API. The following members can be updated by changing the defines:

```
// Version number for this application (uint32_t)
#define APP_PROPERTIES_VERSION

// Unique ID (e.g. UUID or GUID) for the product this application is built for (uint8_t[16])
#define APP_PROPERTIES_ID
```

When using the OTA process with Bluetooth AppLoader, a pointer to the application properties struct needs to be set to application vector table vector 13. This is enabled automatically when using the default startup file and the struct name is `sl_app_properties`.

3.4 NCP Applications

When developing applications for an external host, the `SL_BT_API_FULL` define needs to be defined to prevent the linker from dropping the BGAPI command implementation from the application. The define includes a full implementation of all enabled BGAPI classes in the application.

3.5 RTOS Support

The Bluetooth stack is usually run on bare metal configuration, but the Bluetooth stack can also run on Micrium RTOS and FreeRTOS. When the application project includes an RTOS kernel, the Bluetooth RTOS adaptation component with the following files is automatically added to the application:

sl_bt_rtos_adaptation.c

sl_bt_rtos_adaptation.h

sl_bt_rtos_config.h

sl_bt_rtos_adaptation.c and sl_bt_rtos_adaptation.h

`sl_bt_rtos_adaptation.c` and `sl_bt_rtos_adaptation.h` provide the RTOS tasks for the IPC (Inter-Process Communication) with the Bluetooth stack and other RTOS tasks using CMSIS-RTOS2.

sl_bt_rtos_config.h

`sl_bt_rtos_config.h` is used to set the Bluetooth RTOS task priorities and the stack sizes.

When the project is generated, the SLC tools will automatically contribute the relevant Bluetooth stack configuration and initialization to enable the Bluetooth stack to work with the RTOS.

3.6 Multiprotocol Support

When the Bluetooth Stack is used in a multiprotocol environment, the application must use the RAIL library with multiprotocol support. When the application uses multiprotocol RAIL library, the SLC tools automatically include relevant initialization for Bluetooth multiprotocol support.

3.7 Platform Components

The Bluetooth SDK relies on many platform components that are part of the underlying Gecko Platform infrastructure of the Simplicity SDK Suite. The `autogen` folder contains the source code generated by SLC tools for initializing the hardware and processing events. The `config` folder includes hardware and stack configuration options.

4. Configuring the Bluetooth Stack and a Wireless Gecko Device

To run the Bluetooth stack and an application on a Wireless Gecko, the MCU and its peripherals must be properly configured. The application project configuration consists of selecting the Platform and Bluetooth components that the application needs and setting the configurable values for each selected component. Application projects are generated using Silicon Labs Configurator (SLC) tools that read the project description from a .slcp file and generate the relevant files and build rules. An application can be generated using either the Project Configurator in Simplicity Studio 5 (SSv5) or the SLC-CLI (see *UG520: Software Project Generation and Configuration with SLC-CLI*). The files generated by the SLC tools take care of initializing and setting the configuration for the selected components.

4.1 Wireless Gecko MCU and Peripherals Configuration

sl_system_init()

The `sl_system_init()` function is used to initialize the system. It will call platform, driver, service, stack, and internal app init functions, which are located in the `autogen` folder.

App_init()

The `App_init()` function is used to initialize application-specific features.

4.1.1 Bluetooth Clocks

The Bluetooth clocks are configured and initialized with clock manager by including `clock_manager` component in the application project.

The clock settings are initialized in the `sl_platform_init()` function in `sl_event_handler.c`. Clock settings include initializations of oscillators (HFXO, LFXO, and LFRCO) with parameters such as tuning, initialization of the clocks (HFCLK, LFCLK, LFA, LFB, LFE), and the assignment of clocks to oscillators. Note: The peripheral clocks (like GPIO clock, TIMER clock) are not enabled in this function. They must be enabled when initializing a peripheral.

HFCLK

HFCLK is used for a radio protocol timer (PROTIMER). HFCLK is a high frequency clock where accuracy must be at least ± 50 ppm. This clock needs an external crystal to be sufficiently accurate (HFXO).

The HFXO initialization configures the external crystals for timing-critical connection and sleep management. An HFXO has to be set as the high frequency clock (HFCLK) and physically connected to a Wireless Gecko's HFXO input pins.

LFCLK

LFCLK, the low frequency clock, is used for two purposes. In the Bluetooth stack, it is used for Bluetooth protocol timing. It is also needed to keep track of time during sleep mode.

When a device enters into sleep mode, the current state of PROTIMER is saved. When the device wakes up, it calculates how many ticks of sleep clock have passed and adjusts the PROTIMER accordingly. To the radio it appears that PROTIMER has been constantly ticking.

The accuracy of this clock depends on the operating mode of the device. When advertising or scanning, accuracy is not that important, but when a connection is open, the accuracy must be at least ± 500 ppm. This clock can be driven either by LFXO or LFRCO, depending on the accuracy requirements. If applications only require advertising or scanning, LFRCO can be used as the clock source. However, if Bluetooth connections are required, the clock source must be either LFXO or LFRCO with High Precision Mode. When using LFRCO, the accuracy of the clock must be configured to ± 500 ppm.

In the default configuration, LFXO is connected to the Wireless Gecko and set as the clock source for LFCLK. If the design only has PLFRCO or LFRCO with High Precision Mode, PLFRCO or LFRCO is connected and set as the clock source.

If none of LFXO or LFRCO with High Precision Mode is connected in the design, sleeping is disabled automatically if LF clock accuracy does not meet the 500 ppm requirement.

HFRCODPLL

HFRCODPLL is a high frequency clock that is used as a system clock with the Bluetooth stack. On EFR32[M|B]G21x, HFRCODPLL needs to be configured to 80 MHz and set as the system clock source.

CTUNE

The examples have the crystal tune (CTUNE) settings for both HFXO and LFXO set by default to work with all of the Silicon Labs' Bluetooth modules, reference designs, and radio boards. However, in some cases the end-product design requires specific crystal calibration, either per device or per design. The CTUNE value can be adjusted according to the design using the clock manager.

For more information on configuring the HFXO and LFXO, refer to the EFR32 Reference Manual.

Default HFXO CTUNE Value

The system checks multiple sources for the default HFXO CTUNE value, using the following logical order:

1. CTUNE PSKEY is set. This key has ID 50 (32 in hex) and contains 2 bytes of data for the 16 bit CTUNE value. This can be programmed with the BGAPI command `sl_bt_nvm_save`. **This method is not recommended.**
2. Calibration value exists in DEVINFO. Some modules contain a factory-programmed value in the DEVINFO-page.
3. Manufacturing token exists in the user data page. This is programmed by the developer, or it can be automatically set by Simplicity Studio if the board EEPROM contains the value. This token consists of 2 bytes, located at offset 0x0100 from the starting address of the User Data page. Refer to AN961: Bringing Up Custom Devices for the EFR32MG and EFR32FG Families to how to use manufacturing tokens.
4. If a radio board is selected when generating the project, then use default value from board header file.
5. If nothing else is found, use the default value from CMU header file.

Setting CTUNE via the BGAPI and NVM3 (step 1 above) is a Bluetooth-specific solution and is not recommended for new designs. New designs and applications should use the CTUNE setting mechanisms provided by the platform components, as these guarantee proper CTUNE settings regardless of which wireless stacks are running.

4.1.2 DC-DC Configuration

On devices that have DC-DC, the configuration is set in the `sl_device_init_dcdc()` function in `sl_event_handler.c`. The examples in the SDK have DC-DC configuration set to work with the Silicon Labs' Bluetooth modules, radio boards, and reference designs, but custom designs might require specific DC-DC settings. These custom settings can be set in `sl_device_init_dcdc_xx.c`.

```
/** DCDC regulator initialization structure. */
typedef struct {
    EMU_DcdcMode_TypeDef      mode;           /**< DCDC mode. */
    EMU_VreginCmpThreshold_TypeDef cmpThreshold; /**< VREGIN comparator threshold. */
    EMU_DcdcTonMaxTimeout_TypeDef tonMax;      /**< Ton max timeout control. */
    bool                      dcmOnlyEn;      /**< DCM only mode enable. */
    EMU_DcdcDriveSpeed_TypeDef driveSpeedEM01; /**< DCDC drive speed in EM0/1. */
    EMU_DcdcDriveSpeed_TypeDef driveSpeedEM23; /**< DCDC drive speed in EM2/3. */
    EMU_DcdcPeakCurrent_TypeDef peakCurrentEM01; /**< EM0/1 peak current setting. */
    EMU_DcdcPeakCurrent_TypeDef peakCurrentEM23; /**< EM2/3 peak current setting. */
} EMU_DCDCInit_TypeDef;
```

For more information on configuring the DC-DC, refer to the EFR32 Reference Manual, Chapter 11, and *AN0948: Power Configurations and DC-DC*.

4.1.3 LNA

A low-noise amplifier (LNA) is an electronic amplifier that amplifies a very low-power signal without significantly degrading its signal-to-noise ratio. The LNA improves RF sensitivity.

An LNA is provided on-board in some MGM12P modules as part of front-end module (FEM). To use LNA in these modules, the FEM needs to be correctly configured and enabled. The FEM is configured in `sl_fem_util_config.h`.

FEM is initialized in `sl_fem_util_init()` within the `sl_service_init()` function if the board supports FEM.

4.1.4 PTI

PTI (Packet Trace Interface) is a built-in block in the Wireless Gecko SoCs to route incoming and outgoing radio packets as raw data to the debug interface. These packets can then be captured and displayed in Simplicity Studio's Network Analyzer. Network Analyzer has a decoder for Bluetooth packets and can be used to debug, analyze, and measure Bluetooth networks.

PTI is initialized in `sl_rail_util_pti_init()` within the `sl_stack_init()` function. The baudrate can be set using the `SL_RAIL_UTIL_PTI_BAUD_RATE_HZ` definition, and pins can be configured using the definitions with the `SL_RAIL_UTIL_PTI_DOUT_` and `SL_RAIL_UTIL_PTI_DFRAME_` prefix in `sl_rail_util_pti_config.h`.

4.1.5 Transmit Power

Transmit power of Bluetooth depends on the maximum power allowed by the radio, the software configuration, RF path gain compensation, and usage of Adaptive Frequency Hopping (AFH).

The ETSI EN 300 328 standard requires using AFH when transmitter power is +10 dBm and over.

The maximum allowed power is limited to less than +10 dBm if prevented by adaptivity requirements. The ETSI standard requires that at least 15 channels are in use for AFH. This requirement prevents using +10 dBm and over in the following cases: legacy advertising, scan responses, and in connections, when not enough channels are available.

4.1.6 Wi-Fi coexistence

Wi-Fi coexistence (COEX) is a protocol where Bluetooth and Wi-Fi arbitrate which protocol can use the radio for transmitting. When enabled, it improves the performance of Wi-Fi and Bluetooth. The application can include the COEX functionality by including the `rail_util_coex` component and configuring it in `sl_rail_util_coex_config.h`.

4.1.7 MbedTLS

The MbedTLS cryptography library used by the stack is configured using a configuration file that defines which algorithms are supported, and if the implementation uses hardware acceleration or is done on software. The Bluetooth stack uses the new PSA crypto API for crypto operations. In addition to enabling crypto operations, the PSA crypto API enables storing long-term encryption keys encrypted on flash in Vault-enabled devices.

The MbedTLS needs to be initialized with `sl_mbedtls_init()`. The MbedTLS configuration file path is given using `#define MBEDTLS_CONFIG_FILE`. The default configuration files `config/mbedtls_config.h`, `autogen/mbedtls_config_autogen.h`, `config/psa_crypto_config.h`, and `autogen/psa_crypto_config_autogen.h` should be used as a template if the configuration needs to be changed.

In PSA crypto API, only a certain number of keys can be open at one time. Bluetooth pairing requires that 2 keys are open at the same time. By default, no key slots are reserved for the application to save RAM. If the application uses PSA crypto API, then the `SL_PSA_KEY_USER_SLOT_COUNT` setting must be set to the value of the number of keys the application needs to stay open simultaneously. This can be changed with the `SL_PSA_KEY_USER_SLOT_COUNT` setting located in `config/psa_crypto_config.h`. Each key slot will use 40 bytes of RAM.

If any MbedTLS errors occur when the Bluetooth stack is using crypto operations, `sl_bt_evt_system_error` is sent with the status set as `SL_STATUS_BT_CRYPTO` and the data field containing the actual MbedTLS error code.

Note that the actual Bluetooth connection encryption uses RADIOAES, which does not have DPA countermeasures. RADIOAES only has access to temporary session keys.

4.2 Bluetooth Stack Configuration

The Bluetooth stack core component, `bluetooth_stack`, is available in all versions of the Bluetooth SDK and must always be included when the application wants to use Bluetooth functionality. The Bluetooth feature components represent features and functionalities that an application may optionally include into the build. To minimize the code size and flash usage, applications are encouraged to only include those feature components that the application requires. Most Bluetooth feature components correspond to a BGAPI class in the Bluetooth API. When the corresponding component is not included in the application project, the API class is not available, and its commands will return an error at runtime.

The set of available Bluetooth feature components can vary depending on the Bluetooth SDK version. Consult the API documentation and the components in the SDK that you are working with. The available configuration options may also differ between Bluetooth SDK versions. Some Bluetooth configuration parameters are part of the core component, `bluetooth_stack`, while some parameters are part of the optional feature component. Each component that provides configurable parameters has an associated configuration header. Consult the configuration headers or the Project Configurator in the Simplicity Studio to see the description of each configuration parameter.

The subsections below describe some Bluetooth components or functionalities that affect Bluetooth as a whole or have special configuration considerations.

4.2.1 Bluetooth On-Demand Start

With the Bluetooth on-demand start feature, the application can start and stop the Bluetooth stack from running when needed. The feature is enabled by including the `bluetooth_on_demand_start` component. When this feature is enabled, the Bluetooth stack does not run until `sl_bt_system_start_bluetooth()` is called. The main purpose of this feature is for the DMP use case, where Bluetooth is not needed all the time, and resources need to be freed for other application uses. The Bluetooth stack can be stopped with `sl_bt_system_stop_bluetooth()`, which gracefully restores Bluetooth to an idle state by disconnecting any active connections and stopping any ongoing advertising and scanning. Any resources that were allocated when the stack was started are freed when the stack is stopped. When the Bluetooth stack is not running, all BGAPI classes other than System become unavailable.

If this feature is not enabled, Bluetooth stack is started automatically at boot time.

4.2.2 Bluetooth Buffer Memory

The Bluetooth stack uses memory for buffering API events and the data transmitted in Bluetooth connections, advertising, and scanning. This buffer memory is allocated from the heap when the Bluetooth stack is started. The size of buffer memory in bytes is defined by C-define `SL_BT_CONFIG_BUFFER_SIZE` in *sl_bluetooth_config.h*. The default value is an estimation for achieving adequate throughput and supporting multiple simultaneous connections. Consider increasing this value if the application needs higher data throughput over connections, or uses advertising or scanning with long advertisement data.

4.2.3 Number of Connections

The absolute maximum number of simultaneous Bluetooth connections is 32. The amount of memory that is allocated for connection management further limits the number of connections. The memory is allocated from the heap when the Bluetooth stack is started. C-define `SL_BT_CONFIG_MAX_CONNECTIONS` in *sl_bluetooth_config.h* can be defined to set the number of connections.

4.2.4 Software Timers

The maximum number of available software timers can be configured by C-define `SL_BT_CONFIG_MAX_SOFTWARE_TIMERS` in *sl_bluetooth_config.h*. Each timer needs resources from the stack to be implemented. Increasing the number of soft timers may cause degraded performance in some use cases. Instead of using software timers, the recommend way for using timers is to use `sleeptimer` component.

4.2.5 TX Power and RF Path

TX Power

The system scope maximum TX power for Bluetooth can be configured by C-define `SL_BT_CONFIG_MAX_TX_POWER`. It specifies the maximum TX power for Bluetooth connections, advertising, scanning, and DTM testing.

The C-define `SL_BT_CONFIG_MIN_TX_POWER` is used only by the LE Power Control feature. It specifies the minimum TX power level for Bluetooth connections and DTM testing.

Gain

The application can define RF path gain values for RX and TX separately. Positive values mean gain on the given RF path, while negative values mean loss.

The Bluetooth stack takes TX RF path gain into account when setting TX power. The TX power is automatically adjusted so that the power radiated from the antenna matches the application request. For example, if maximum power requested by the application is at +10 dBm and path loss is -1 dB, then actual power at the RF pin is set to +11 dBm.

The TX RF path gain must be set with care and correspond to reality. The stack put limits on the TX power to comply with RF regulations. If the TX RF path gain is not set properly, the device may violate the regulations and may not pass RF certification!

Note: This setting is not meant for modules with integral antennas and should be ignored for such devices.

RX RF path gain is used to compensate the RSSI reports from the Bluetooth Stack.

```
.rf.tx_gain = -20; // RF TX path gain in unit of 0.1 dB. -20 means -2 dB loss on the TX RF path.  
.rf.rx_gain = -18; // RF RX path gain in unit of 0.1 dB. -18 means -1.8 dB loss on the RX RF path.
```

Output selection

On EFR32[M|B]G21 SoC-based designs, the RF output can be selected.

```
.rf.flags = SL_BT_RF_CONFIG_ANTENNA; // enabling output configuration  
.rf.antenna = 0; // desired output,
```

For the correct value refer to the antenna path selection in the RAIL header file `rail_chip_specific.h`.

4.2.6 Security Manager

To enable the Security Manager in the Bluetooth stack, the application needs to include the `bluetooth_feature_sm` component into the application project. It is important to configure the Security Manager properly to ensure that security requirements can be achieved. Use `sl_bt_sm_configure()` to set security flags and device's IO capabilities. The IO capabilities define which pairing methods are possible and should be set to match the device's capabilities. The security flags can be used to enforce certain security settings, such as requiring that pairing always uses bondable mode, pairing only uses secure connections, or whether authentication is required. Security Manager also has a flag to indicate whether authenticated or non-authenticated pairing is preferred if both are possible. If this flag is not set, and even if both devices' IO capabilities allow authenticated bonding, it is not used if neither device requests authentication. Refer to the available options in API documentation, [Security Manager](#).

The number of bondings that can be stored in the bonding database is set with `sl_bt_sm_store_bonding_configuration()`. This command is also used to define what happens if the bonding database becomes full. Pairings are not stored in the bonding database unless both devices are in bondable mode. Enable the bondable mode with `sl_bt_sm_set_bondable_mode()`. Including the `bluetooth_feature_external_bonding_database` component can be used to handle storing bonding data by the application. This can be useful with applications that require a large number of bondings. With the external bonding database component, the Bluetooth stack does not limit the number of bondings.

4.2.7 Adaptive Frequency Hopping

Bluetooth Stack implements Adaptive Frequency Hopping (AFH), conforming with the ETSI EN 300 328 standard. AFH is required when using transmit power +10 dBm and over. AFH may also provide performance improvement by avoiding congested channels.

To enable AFH in the Bluetooth stack, the application must include the `bluetooth_feature_afh` component. In a central-peripheral connection, both ends can use AFH independent of each other. The central device may be non-adaptive, but the peripheral still may need to be adaptive. The standard allows using control transfer on a blocked channel. For compliance reasons, if the peripheral detects that a blocked channel is in use, it will only send a single packet on that channel to prevent connection timeouts.

Note: Legacy advertising does NOT use Adaptive Frequency Hopping. Legacy advertising uses 3 channels, and AFH needs a minimum of 15 channels to fulfill the requirements of the ETSI standard. Extended advertising must be used to enable AFH with advertising.

4.2.8 Even Connection Distribution Algorithm

The even connection distribution algorithm is designed to be used especially with applications that involve several concurrent connections. The algorithm tries to distribute the connections such a way that they are distributed over time as evenly as possible without overlapping, and all connections should get an equal share of the air interface resource.

For optimal performance, the algorithm user should:

- Initiate the first connection with the longest connection interval if all connections do not have the same interval.
- Set the connection intervals of the other connections such that they are, or allow (via min-max range), integer fractions of the first interval.
- Make the first interval long enough such that all connections would fit within the interval with a reasonable transmission time.

The algorithm and the connections can be expected to work if the above recommendations are not followed, but performance will not likely be optimal.

By default, the link layer uses the legacy Random Connection Distribution algorithm. The Even Connection Distribution algorithm can be enabled by including the component `bluetooth_feature_ll_even_scheduling` or calling link layer function `ll_connSchAlgorithmEvenEnable()` during the software initialization phase. As the even connection scheduling mechanism is meant to be used with multiple (up to 32) concurrent connections, the buffer size is recommended to be increased as follows.

```
SL_BT_CONFIG_BUFFER_SIZE 20160
```


4.2.9 Multiprotocol Priority Configuration

When the Bluetooth stack is used with other protocols in a multiprotocol environment, it may become necessary to change the Bluetooth priority settings for RAIL to optimize certain use cases.

The application needs to allocate the configuration struct and provide it for the Bluetooth stack:

```
sl_bt_bluetooth_ll_priorities custom_priorities;
static const sl_bt_configuration_t config = {
    //
    .bluetooth.linklayer_priorities = &custom_priorities,
    //
};
```

The `sl_bt_bluetooth_ll_priorities` struct must be initialized to default state by the `SL_BT_BLUETOOTH_PRIORITIES_DEFAULT` constant.

The `sl_bt_bluetooth_ll_priorities` struct contains following fields:

- `scan_min`, `scan_max`, `scan step` - The priority range for scan operation.
- `adv_min`, `adv_max`, `adv step` - The priority range for advertisement operation.
- `conn_min` & `conn_max` - The priority range for connection packets.
- `init_min` & `init_max` - The priority range for connection initiation.
- `rail_mapping_offset` - The RAIL priority level where Bluetooth priorities are located.
- `rail_mapping_range` - The RAIL priority range where Bluetooth priorities are located.

For each priority range, 0 is the maximum priority, and 0xff is the minimum priority. Bluetooth priorities are different from RAIL priorities. That is, Bluetooth has its own space between 0 and 0xff where all Bluetooth priorities are located. To map Bluetooth priorities to RAIL priorities, the values in fields `rail_mapping_offset` and `rail_mapping_range` are used to form single-degree equation:

```
RAIL_priority=(BT_priority/0xFF)*rail_mapping_range+rail_mapping_offset
```

4.2.10 Sleep

Wireless Gecko's sleep mode EM2 (energy mode two) is managed by the platform `power_manager_deepsleep` component. Including the component automatically enables deep sleep. Including the `power_manager_no_deepsleep` component in the application will disable deep sleep.

The sleep modes require that an accurate 32 kHz low-frequency clock (LFCLK) is present in the hardware. If an accurate sleep clock is not available for the Bluetooth stack and the application must support Bluetooth connections or periodic advertising synchronizations, then low power sleep modes cannot be entered. For applications where low power sleep modes are not needed, the LFXO or LFRCO can be left out.

Disabling Sleep at Runtime

If the application needs to disable sleep at runtime, it can be done by implementing `bool app_is_ok_to_sleep()` function. The function is called when the device wants to sleep. While EM2 is disabled (/blocked), the stack will switch between EM0 and EM1. For more information, refer to Power Manager documentation.

4.2.11 PA

On EFR32 SoC-based designs, the Power Amplifier (PA) configuration comes from component `rail_util_pa`, the utility to aid with RAIL RF PA Support.

4.3 OTA Configuration

Configuration of the AppLoader is done using the configuration options in the `bootloader_apploader` component.

Note that setting the device to OTA DFU mode should be secured so that only trusted devices have that capability.

For more details about OTA firmware updates, refer to *UG266: Silicon Labs Gecko Bootloader User's Guide* and *AN1086: Using the Gecko Bootloader with Silicon Labs Bluetooth Applications*.

4.4 Radio Co-Processor Mode

The Bluetooth controller can be used in Radio Co-Processor (RCP) mode with HCI interface. The link layer must be configured with vendor-specific HCI commands to allocate dynamic memory structures before the link layer can be used.

For more details about the RCP mode, refer to *AN1328: Enabling a Radio Co-Processor using the Bluetooth LE HCI Function*.

5. Bluetooth Stack Event Handling

The Bluetooth stack for the Wireless Geckos is an event-driven architecture, where events are handled in the main while loop of the application on bare metal.

5.1 Commands from Multiple Tasks

It is possible to send Bluetooth commands from multiple OS tasks. All BGAPI command functions have automatic locking to make them thread-safe. Using `sl_bt_bluetooth_pend()` and `sl_bt_bluetooth_post()` is therefore no longer required for individual calls to the BGAPI.

The application only needs to use `sl_bt_bluetooth_pend()` and `sl_bt_bluetooth_post()` to protect sections of code where multiple commands need to be performed atomically in a thread-safe manner. This includes cases such as using `sl_bt_system_data_buffer_write()` to write data to the system buffer followed by a call to `sl_bt_extended_advertiser_set_long_data()` to set that data to an advertiser set. To synchronize access to the shared system buffer, the application needs to lock by calling `sl_bt_bluetooth_pend()` before `sl_bt_system_data_buffer_write()`, and release the lock by calling `sl_bt_bluetooth_post()` after `sl_bt_extended_advertiser_set_long_data()`.

6. Interrupts

Interrupts create events in their respective interrupt handlers, be it radio interrupts or interrupts from IO pins. The events are later processed in the main event loop from the message queue. The application should always minimize the processing time within an interrupt handler, and leave the processing for event callbacks or to the main loop.

In general, the interrupt scheme is according to any event-based programming architecture, but a few unique and important exceptions apply to the Bluetooth stack:

- BGAPI commands cannot be called from interrupt context.
- Only the `sl_bt_external_signal()` function can be called from interrupt context.

6.1 External Event

An external event is used to capture all peripheral interrupts as an external signal to be passed to the main event loop and to be processed within that loop. The external event interrupt can come from any of the peripheral interrupt sources, for example IOs, comparators, or ADCs, to name a few. The signal bit array is used for notifying the event handler of what external interrupts have been issued.

- The main purpose of the external signal is to trigger an event from the interrupt context to the main event loop.
- The BGAPI event `sl_bt_evt_system_external_signal` can be generated by calling the `void sl_bt_external_signal(uint32 signals)` function.
- The function `sl_bt_external_signal` can be called from the interrupt context. If the Platform Core Interrupt API has been configured to use the `CORE_ATOMIC_METHOD_BASEPRI` as the implementation method of atomic sections, which is the default configuration, this function must not be called from an interrupt handler with a priority higher than `CORE_ATOMIC_BASE_PRIORITY_LEVEL`.
- The `signals` parameter of the `sl_bt_external_signal` function is passed to the `sl_bt_evt_system_external_signal` event.

```

/*****
 * Bluetooth stack event handler.
 *
 * @param[in] evt The event coming from the Bluetooth stack
 *****/
void sl_bt_on_event(sl_bt_msg_t *evt)
{
    ...
    switch (SL_BT_MSG_ID(evt->header)) {
        ...

        case sl_bt_evt_system_external_signal_id:
            // External signal indication (comes from the interrupt handler)
            // Handle GPIO IRQ and do something
            // External signal command's parameter can be accessed using
            // evt->data.evt_system_external_signal.extsignals
            break;

        ...
    }
}

/**
 * Handle GPIO interrupts and trigger system_external_signal event
 */
void GPIO_ODD_IRQHandler()
{
    static bool radioHalted = false;

    uint32_t flags = GPIO_IntGet();
    GPIO_IntClear(flags);

    //Send gecko_evt_system_external_signal_id event to the main loop sl_bt_external_signal(...);
}

```

6.2 Priorities

The Bluetooth link layer will always execute the most time-critical sections in the radio interrupt directly. Additionally, in a bare metal build, the Bluetooth link layer will use the PendSV interrupt to have higher priority than the Bluetooth host stack or the application code. When an RTOS is included, RTOS task priorities are used to give the link layer the higher priority. Silicon Labs recommends that the radio should have the highest priority interrupts. This is the default configuration, and other interrupts are handled with lower priority. The interrupt priority for the radio is 4; for the Link Layer PendSV interrupt in the bare metal build, the priority is 5; and other interrupts have a default priority of 7. Smaller value is a higher priority interrupt.

To guarantee the proper operation of atomic sections in the Bluetooth stack, the atomic sections need to be configured correctly with respect to the interrupt priorities. Silicon Labs recommends that the `BASEPRI` register is used instead of the `PRIMASK` register, i.e., `CORE_ATOMIC_METHOD` is configured to `CORE_ATOMIC_METHOD_BASEPRI`. This is the default configuration. When using `CORE_ATOMIC_METHOD_BASEPRI`, the `CORE_ATOMIC_BASE_PRIORITY_LEVEL` needs to be set to an equal or higher priority (equal or smaller value) than the radio interrupt and the PendSV interrupt (in bare metal). The default value of `CORE_ATOMIC_BASE_PRIORITY_LEVEL` is 3, which is consistent with the default radio interrupt priority 4, and the default link layer PendSV interrupt priority 5 (on bare metal).

For more details on the interrupt configuration and atomic sections, see the [Core Interrupt](#) documentation.

The following table describes the three different components within the Bluetooth stack that run in different operating contexts, and their maximum time to disable interrupts for each component to assure connections.

| Component | Description | Timing Accuracy | Operating Context | Maximum IRQ Disable | If Timing Requirements are Ignored |
|------------|---|-----------------|-------------------|---------------------|--|
| Radio | Time-critical low level TX/RX radio control | Microseconds | Radio IRQ | < ~10 μ s | Packets are not transmitted or received, which will eventually cause supervision timeout and Bluetooth link loss. |
| Link layer | Time-critical connection management procedures and encryption | Milliseconds | PendSV IRQ (1) | < ~20 ms | If the link control procedure is not handled in time, Bluetooth link loss may happen. Peripheral-side channel map update and connection update timings are controlled by central device. |
| Host Stack | Bluetooth Host Stack, Security Manager, GATT | Seconds | Application | < 30 s | SMP and GATT have a 30 s timeout and if operations are not handled within that timeout Bluetooth link loss will occur. |

(1) PendSV interrupt is only used without RTOS

7. Wireless Gecko Resources

The Bluetooth stack uses some of the Wireless Gecko's resources, which are not available to the application. The following table lists the resources and describes their use by the stack. The first four resources (in red) are always used by the Bluetooth stack.

| Category | Resource | Used in software | Notes |
|----------|-------------------------------------|-----------------------------------|---|
| PRS | PRS7 | PROTIMER RTC synchroni- zation | PRS7 always used by the Bluetooth stack. |
| Timers | RTCC | EM2 timings | The sleep timer uses RTCC in the default configuration. In EFR32[M B]G22, RTCC can be used by applications if the sleep timer is configured to use another resource. See platform sleeptimer documen- tation . |
| | PROTIMER | Bluetooth | The application does not have access to PROTIMER. |
| Radio | RADIO | Bluetooth | Always used and all radio registers are reserved for the Bluetooth stack. |
| GPIO | NCP | Host communication. | 2 to 6 x I/O pins can be allocated for the NCP usage depending on used features (UART, RTS/CTS, wake-up and host wake-up). Optional to use, and valid only for NCP use case. |
| | PTI | Packet trace | 2 to N x I/O pins. Optional to use. |
| | TX enable | TX activity indication | 1 x I/O pin. Optional to use. |
| | RX enable | RX activity indication | 1 x I/O pin. Optional to use. |
| | COEX | Wi-Fi coexistence | 4 x I/O pin. Optional to use. |
| CRC | GPCRC | NVM3/PS Store | Can be used in application, but application should always reconfigure GPCRC before use, and GPCRC clock must not be disabled in CMU. |
| Flash | MSC | NVM3/PS Store | Can be used by the application. |
| CRYPTO | CRYPTO/ Secure Ele- ment (SE) | Bluetooth link encryption | The CRYPTO/SE peripheral can only be accessed through the mbedTLS crypto library, not through any other means. The library should be able to do the scheduling between the stack and application access. |
| | RADIOAES | Bluetooth link encryption | The application does not have access to RADIOAES |

7.1 Flash

The application and Bluetooth stack are executed from the flash memory. The flash can be split into blocks for the bootloader and the Bluetooth AppLoader, application + Bluetooth stack, and non-volatile memory, as shown in the following figure.

- The bootloader is essential to enable Bluetooth stack and application upgradeability. The bootloader has been designed to be future-proof for bootloader improvements and feature additions.
- The Bluetooth AppLoader provides OTA upgradability for the application. This is an optional feature, but using it requires that the bootloader is also used and it is implemented as bootloader communication plugin.
- NVM3 is a non-volatile data store (NVM), where both the Bluetooth stack and the application can store permanent data, such as Bluetooth bonding keys, application configuration data, hardware configurations, and so on.
- The application is located between the bootloader and NVM. The Bluetooth stack is a library that is linked with the application. The Bluetooth stack includes the actual Bluetooth firmware, including link layer, GAP, SM, ATT, and GATT layers.
- Manufacturing tokens storage is used for storing manufacturing tokens. It is located at end of main flash.




Figure 7.1. Flash Usage

The following table shows the flash usage for each block. The estimates can vary between use cases, configurations, application resources, or SDK version.

| | Compiler | EFR32[M] B]G21 | EFR32[M] B]G21 with Vault | EFR32[M] B]G22 | EFR32[M] B]G24 | EFR32[M] B]G26 | EFR32[M] B]G27 |
|-------------------------|----------|-------------------|---------------------------------|-------------------|-------------------|-------------------|-------------------|
| Bootloader (1) | - | 16+56 | 16+56 | 24+48 | 24+48 | 24+48 | 24+48 |
| soc-empty (2) | GCC | 173 | 176 | 182 | 192 | 192 | 182 |
| " | IAR | 169 | 172 | 177 | 188 | 187 | 177 |
| NVM3 (3) | - | 40 | 40 | 40 | 40 | 40 | 40 |
| Manufacturing tokens | - | 8 | 8 | 8 | 8 | 40 | 8 |

(1) The bootloader size includes the AppLoader communication plugin. The size in the table is the size reserved for Bootloader and AppLoader by default. The actual size can be smaller.

(2) *bt-soc-empty* is an example application provided in the Bluetooth SDK. It is compiled with high size optimizations. GCC uses the `-Os` flag, and IAR the `-Ohz` flag.

(3) NVM3 requires a minimum of 3 flash pages; the default configuration in the Bluetooth sample applications is 5 pages in the SDK. Please refer to *AN1135: Using Third Generation Non-Volatile Memory (NVM3) Data Storage* for further information about NVM3.

7.1.1 Optimizing Flash Usage

Dead Code Elimination

Bluetooth stack libraries are designed to benefit from the linker's dead code elimination optimization. With this optimization all unused code will be removed from application. Selected host stack GCC libraries have enabled LTO support with compiling options `-flto` and `-ffat-lto-objects`. This will help the linker to optimize unused code from the application.

To fully utilize this optimization feature, it is important not to call any function that is not needed for application. These include all initialization functions for the Bluetooth stack.

Selective Initialization of Bluetooth Stack Components

Each required stack component must be individually initialized. For more information, see section [4.2 Bluetooth Stack Configuration](#).

7.1.2 Bluetooth Bonding Database

Bluetooth bonding database is stored in NVM. NVM3 size must be set so that the required number of bondings can fit to it. The following table shows how much NVM3 space each bonding will require at maximum in bytes including NVM3 overheads. The bonding database uses PSA ITS (internal trusted store) for storing the keys.

| | EFR32[M B]G2x | EFR32[M B]G2x with Vault |
|----------------------------|---------------|--------------------------|
| Secure Connections Pairing | 211 | 299 |
| Legacy Pairing | 311 | 443 |

Note that during the first boot, the device tries to import keys from the old bonding database used in the SDK v3.1.1 and older into PSA ITS. If IRK (privacy key) import fails, all existing bondings are deleted, because IRK is shared with bonded devices. If importing certain bonding fails, that bonding is erased and importing will continue with the next one.

When deployed to Secure Vault High devices, sensitive keys such as the Long Term Key (LTK) are protected using the Secure Vault Key Management functionality. The table below shows the protected keys and their storage protection characteristics.

| Wrapped Key | Exportable/Non-Exportable | Notes |
|-------------------------------------|---------------------------|---|
| Remote Long Term Key (LTK) | Non-Exportable | - |
| Local Long Term Key (legacy only) | Non-Exportable | - |
| Remote Identity Resolving Key (IRK) | Exportable | Must be Exportable for future compatibility reasons |
| Local Identity Resolving Key (IRK) | Exportable | Must be Exportable because the key is shared with other devices |

Wrapped keys that are “Non-Exportable” can be used, but cannot be viewed or shared at runtime. Wrapped keys that are “Exportable” can be used or shared at runtime, but remain encrypted while stored in flash.

When the `bluetooth_feature_external_bonding_database` component is used, the application is responsible for storing the persistent bonding information. The Bluetooth stack will only store the local identity resolving key internally in this case.

7.2 Linking

The Bluetooth stack is delivered as a set of library files. The application links the Bluetooth stack libraries with the rest of application. The linker will then create an ELF-file, which contains the application code and data ready to be loaded into flash.

For generating OTA DFU files, the application's code and data must be linked into their own section in the ELF-file. This is automatically done with the linker files provided with the Gecko Platform.

The linker file reserves some memory from main flash for the bootloader. If AppLoader is included with the bootloader the space reserved for the bootloader is automatically increased when the application includes `apploader` component.

For more information on the OTA updates and how to enable them, please refer to *UG489: Silicon Labs Gecko Bootloader User's Guide for GSDK 4.0 and Higher* and *AN1086: Using the Gecko Bootloader with Silicon Labs Bluetooth Applications*.

7.3 RAM

The Bluetooth stack reserves part of the RAM from the Wireless Gecko and leaves the unused RAM for the application.

RAM consumption of the Bluetooth functionality is divided into:

- Bluetooth stack
- Bluetooth object pools
- Bluetooth buffer memory
- Bluetooth GATT database
- C STACK
- C HEAP

The following table shows the RAM allocations that are done statically at link time.

| Component | Static allocation at link time | Configurable by |
|-------------------------|---|-----------------|
| Bluetooth stack | 6 kB | |
| Bluetooth GATT database | Application-dependent (20 to 200 bytes) | |
| Call stack | 2752 bytes | SL_STACK_SIZE |

The following table shows the RAM allocations that are done dynamically from the heap at run time.

| Component | Dynamic heap allocation at run time | Configurable by |
|--|-------------------------------------|--|
| Bluetooth stack | 2 kB | |
| Bluetooth connection objects | 1600 bytes = 400 bytes * 4 | SL_BT_CONFIG_MAX_CONNECTIONS |
| Bluetooth advertiser objects | 160 bytes = 160 bytes * 1 | SL_BT_CONFIG_USER_ADVERTISERS |
| Bluetooth periodic advertising synchronization objects | 0 bytes = 168 bytes * 0 | SL_BT_CONFIG_MAX_PERIODIC_ADVERTISING_SYNC |
| Bluetooth software timers | 160 bytes = 40 bytes * 4 | SL_BT_CONFIG_MAX_SOFTWARE_TIMERS |
| Bluetooth buffer memory | 3150 bytes | SL_BT_CONFIG_BUFFER_SIZE |

7.3.1 Bluetooth Stack

The Bluetooth stack allocates around 6 kB of static RAM and 2 kB of heap for its internal use. It includes Bluetooth stack software with low-level radio drivers and the application programming interface.

7.3.2 Bluetooth Object Pools

The Bluetooth stack uses memory to store the necessary context for objects such as connections, advertisers, and periodic advertisement synchronizations. The number of these objects depends on the configuration. The table in section [7.3 RAM](#) summarizes the memory usage in the default configuration and shows which configuration items affect the number of objects allocated.

7.3.3 Bluetooth Buffer Memory

The Bluetooth stack uses memory for buffering API events and the data transmitted in Bluetooth connections, advertising, and scanning. This buffer memory is allocated from the heap by the Bluetooth stack when the Bluetooth stack is started. The size of buffer memory in bytes is defined by the C-define `SL_BT_CONFIG_BUFFER_SIZE` in *sl_bluetooth_config.h*. The default value is an estimation for achieving adequate throughput and supporting multiple simultaneous connections. Consider increasing this value if the application needs higher data throughput over connections or uses advertising or scanning with long advertisement data.

7.3.4 Bluetooth GATT Database

The Bluetooth GATT database uses statically-allocated RAM. The amount of RAM used depends on the user-defined GATT database and cannot be generalized. All characteristics with write enabled use as much RAM as their length defined. Plus, every attribute in GATT needs a few bytes of RAM for maintaining the Attribute permissions. Typical RAM usage is approximately 20 to 200 bytes.

7.3.5 Call Stack

The Bluetooth stack requires at minimum a call stack to be reserved from RAM as summarized in the table in section [7.3 RAM](#). Application developers must allocate RAM for the application call stack on top of the memory required by the stack. The size of the call stack is configured by `SL_STACK_SIZE` in *sl_memory_config.h*.

7.3.6 Heap memory

The Bluetooth stack uses the heap to allocate storage for object contexts and the stack internal state. In addition to these allocations, the Bluetooth stack requires heap memory for asymmetric encryption operations using the elliptic curve algorithms during Bluetooth pairing.

The heap memory is allocated to the use of any available physical memory that would otherwise have remained unallocated.

8. Application ELF-file

ELF (Executable and Linkable Format) is a standard file format for executable files. This chapter describes the sections in the ELF file related to the application and the Bluetooth stack.

Some linkers provide output describing the consumed flash, but what it contains is not obvious. A Bluetooth project might contain a bootloader and the Bluetooth AppLoader, and the device might have separate flash for the bootloader. The ELF-file provides exact information about RAM and flash usage.

Simplicity Studio provides the GCC toolchain, which contain command line tool *objdump*. This tool can be used to get section information from the ELF-file.

objdump requires input ELF-file. If the parameter *-h* is used, *objdump* dumps the section header information.

IAR

Calling *objdump* from the command line for an example application:

```
arm-none-eabi-objdump -h ewarm-iar/exe/bt_soc_empty.out
```

objdump then gives the following output:

```
Sections:
Idx Name          Size      VMA           LMA           File off  Algn
  0 application    0002f468  08012000  08012000  00000034  2**9
    CONTENTS, ALLOC, LOAD, READONLY, CODE
  1 storage_regions 0000a000  08174000  08174000  0002f49c  2**13
    ALLOC
  2 application_ram 0000279c  20000000  20000000  0002f49c  2**3
    ALLOC
  3 application_heap 0003d860  200027a0  200027a0  0002f49c  2**3
    ALLOC
  4 .debug_abbrev    0000c8ba  00000000  00000000  0002f49c  2**0
    CONTENTS, READONLY, DEBUGGING, OCTETS
  5 .debug_aranges  00008de0  00000000  00000000  0003bd58  2**0
    CONTENTS, READONLY, DEBUGGING, OCTETS
  6 .debug_frame    000186fa  00000000  00000000  00044b38  2**0
    CONTENTS, READONLY, DEBUGGING, OCTETS
  7 .debug_info     00131969  00000000  00000000  0005d234  2**0
    CONTENTS, READONLY, DEBUGGING, OCTETS
  8 .debug_line     0008a871  00000000  00000000  0018eba0  2**0
    CONTENTS, READONLY, DEBUGGING, OCTETS
  9 .debug_loc      00028c5c  00000000  00000000  00219414  2**0
    CONTENTS, READONLY, DEBUGGING, OCTETS
 10 .debug_macinfo  0000d5be  00000000  00000000  00242070  2**0
    CONTENTS, READONLY, DEBUGGING, OCTETS
 11 .debug_pubnames 0000de9f  00000000  00000000  0024f630  2**0
    CONTENTS, READONLY, DEBUGGING, OCTETS
 12 .debug_ranges   00005b28  00000000  00000000  0025d4d0  2**0
    CONTENTS, READONLY, DEBUGGING, OCTETS
 13 .debug_types    0000461e  00000000  00000000  00262ff8  2**0
    CONTENTS, READONLY, DEBUGGING, OCTETS
 14 .iar.debug_frame 0001e0b7  00000000  00000000  00267618  2**0
    CONTENTS, READONLY
 15 .iar.debug_line 000413fd  00000000  00000000  002856d0  2**0
    CONTENTS, READONLY
 16 .comment        0015748a  00000000  00000000  002c6ad0  2**0
    CONTENTS, READONLY
 17 .iar.rtmodel    00000042  00000000  00000000  0041df5c  2**0
    CONTENTS, READONLY
 18 .ARM.attributes 00000032  00000000  00000000  0041dfa0  2**0
    CONTENTS, READONLY
```

application contains the application code and read-only data. Size of the application in this example is 0x2f468 in hexadecimal, and 193640 bytes in decimal.

application_ram is a RAM section for the call stack.

application_heap is the RAM section for heap.

Refer to IAR documentation for description of the remaining sections.

GCC

Calling *objdump* from the command line for an example application:

```
arm-none-eabi-objdump -h build/release/bt_soc_empty.out
```

objdump then gives the following output:

```
Sections:
Idx Name          Size      VMA           LMA           File off  Algn
  0 .vectors        00000170   08012000   08012000   00002000  2**9
    CONTENTS, ALLOC, LOAD, READONLY, DATA
  1 .stack          00000ac0   20000000   20000000   00060000  2**3
    ALLOC
  2 .bss            00001844   20000ac0   20000ac0   00060000  2**3
    ALLOC
  3 text_application_ram 000001ac   20002304   08012170   00002304  2**2
    CONTENTS, ALLOC, LOAD, READONLY, CODE
  4 .text           000302a8   08012320   08012320   00012320  2**4
    CONTENTS, ALLOC, LOAD, READONLY, CODE
  5 .ARM.exidx       00000008   080425c8   080425c8   000425c8  2**2
    CONTENTS, ALLOC, LOAD, READONLY, DATA
  6 .copy.table      0000000c   080425d0   080425d0   000425d0  2**0
    CONTENTS, ALLOC, LOAD, DATA
  7 .zero.table      00000000   080425dc   080425dc   0005269c  2**0
    CONTENTS
  8 .data            000001ec   200024b0   080425dc   000524b0  2**2
    CONTENTS, ALLOC, LOAD, DATA
  9 .memory_manager_heap 00000004   2000269c   080427c8   0005269c  2**0
    ALLOC
10 .nvmm            0000a000   080427c8   080427c8   0005269c  2**0
    CONTENTS
11 .ARM.attributes  00000036   00000000   00000000   0005c69c  2**0
    CONTENTS, READONLY
12 .comment          00000045   00000000   00000000   0005c6d2  2**0
    CONTENTS, READONLY
13 .debug_line_str   000001c0   00000000   00000000   0005c717  2**0
    CONTENTS, READONLY, DEBUGGING, OCTETS
14 .debug_info       00101e0a   00000000   00000000   0005c8d7  2**0
    CONTENTS, READONLY, DEBUGGING, OCTETS
15 .debug_abbrev      0001afa4   00000000   00000000   0015e6e1  2**0
    CONTENTS, READONLY, DEBUGGING, OCTETS
16 .debug_loclists   00036269   00000000   00000000   00179685  2**0
    CONTENTS, READONLY, DEBUGGING, OCTETS
17 .debug_aranges     00009550   00000000   00000000   001af8ee  2**0
    CONTENTS, READONLY, DEBUGGING, OCTETS
18 .debug_rnglists    00009d21   00000000   00000000   001b8e3e  2**0
    CONTENTS, READONLY, DEBUGGING, OCTETS
19 .debug_line        00055c06   00000000   00000000   001c2b5f  2**0
    CONTENTS, READONLY, DEBUGGING, OCTETS
20 .debug_str         00034194   00000000   00000000   00218765  2**0
    CONTENTS, READONLY, DEBUGGING, OCTETS
21 .debug_frame       00015f48   00000000   00000000   0024c8fc  2**2
    CONTENTS, READONLY, DEBUGGING, OCTETS
```

`.text` contains the application code and read-only data. The size of the application in this example is 0x302a8 in hexadecimal and 197288 bytes in decimal.

`.ARM.exidx` is used for debugging.

`.stack` is a RAM section for the call stack


`.data` is the RAM section for initialized variables.

`.bss` is the RAM section for uninitialized variables.

`.memory_manager_heap` is the RAM section for heap.

Refer to GCC documentation for a description of the remaining sections.

9. Documentation



Smart. Connected. Energy-Friendly.



IoT Portfolio
www.silabs.com/products



Quality
www.silabs.com/quality



Support & Community
www.silabs.com/community

Disclaimer

Silicon Labs intends to provide customers with the latest, accurate, and in-depth documentation of all peripherals and modules available for system and software implementers using or intending to use the Silicon Labs products. Characterization data, available modules and peripherals, memory sizes and memory addresses refer to each specific device, and "Typical" parameters provided can and do vary in different applications. Application examples described herein are for illustrative purposes only. Silicon Labs reserves the right to make changes without further notice to the product information, specifications, and descriptions herein, and does not give warranties as to the accuracy or completeness of the included information. Without prior notification, Silicon Labs may update product firmware during the manufacturing process for security or reliability reasons. Such changes will not alter the specifications or the performance of the product. Silicon Labs shall have no liability for the consequences of use of the information supplied in this document. This document does not imply or expressly grant any license to design or fabricate any integrated circuits. The products are not designed or authorized to be used within any FDA Class III devices, applications for which FDA premarket approval is required or Life Support Systems without the specific written consent of Silicon Labs. A "Life Support System" is any product or system intended to support or sustain life and/or health, which, if it fails, can be reasonably expected to result in significant personal injury or death. Silicon Labs products are not designed or authorized for military applications. Silicon Labs products shall under no circumstances be used in weapons of mass destruction including (but not limited to) nuclear, biological or chemical weapons, or missiles capable of delivering such weapons. Silicon Labs disclaims all express and implied warranties and shall not be responsible or liable for any injuries or damages related to use of a Silicon Labs product in such unauthorized applications.

Trademark Information

Silicon Laboratories Inc.[®], Silicon Laboratories[®], Silicon Labs[®], SiLabs[®] and the Silicon Labs logo[®], Bluegiga[®], Bluegiga Logo[®], EFM[®], EFM32[®], EFR, Ember[®], Energy Micro, Energy Micro logo and combinations thereof, "the world's most energy friendly microcontrollers", Redpine Signals[®], WiSeConnect[®], n-Link, EZLink[®], EZRadio[®], EZRadioPRO[®], Gecko[®], Gecko OS, Gecko OS Studio, Precision32[®], Simplicity Studio[®], Telegesis, the Telegesis Logo[®], USBXpress[®], Zentri, the Zentri logo and Zentri DMS, Z-Wave[®], and others are trademarks or registered trademarks of Silicon Labs. ARM, CORTEX, Cortex-M3 and THUMB are trademarks or registered trademarks of ARM Holdings. Keil is a registered trademark of ARM Limited. Wi-Fi is a registered trademark of the Wi-Fi Alliance. All other products or brand names mentioned herein are trademarks of their respective holders.



Silicon Laboratories Inc.
400 West Cesar Chavez
Austin, TX 78701
USA

www.silabs.com