



User Registration

Register today to create your account on Silabs.com. Your personalized profile allows you to receive technical document updates, new product announcements, "how-to" and design documents, product change notices (PCN) and other valuable content available only to registered users.

<http://www.silabs.com/profile>

Bulletin Date: 3/8/2016		Bulletin Effective Date: 3/8/2016	
Title: C8051F93x/92x Errata Rev 0.2			
Originator: Kafai Leung		Phone: 512-532-5232	Dept: Marketing
Customer Contact: Kathy Haggar		Phone: 512-532-5261	Dept: Sales
Bulletin Details			
Description: Silicon Labs is pleased to announce that the following errata is updated and available at www.silabs.com : C8051F93x/92x Revision 0.2 Errata			
Reason: C8051F93x/92x Revision 0.2 errata which includes: <ol style="list-style-type: none"> 1.) Addition of workaround for a slowly decaying VDD ramp. 2.) Addition of Section 2.5 RST_E102 - VDD Monitor Disabled in the errata to explain why a slowly decaying VDD ramp can cause oscillations on the /RST pin and VDD monitor to become disabled. A workaround is suggested by having firmware enable the VDD monitor as the first instruction executed after a reset or in startup routine. This problem is fixed in revision F devices with date codes of 1532 and later.			
Product Identification: C8051F930-F-GM C8051F930-F-GQ C8051F931-F-GM C8051F920-F-GM C8051F920-F-GQ C8051F921-F-GM CF921-PM0606GM CF921-XM0768GM CF930-XL0010GQ C8051F930-F-GMR C8051F930-F-GQR C8051F931-F-GMR C8051F920-F-GMR C8051F920-F-GQR C8051F921-F-GMR CF92x-xxxxxGMR CF93x-xxxxxGMR CF93x-xxxxxGQR CF921-PM0606GMR			



Bulletin #1603081

CF921-XM0768GMR
C8051F930-F-G1DI

Note: The part numbers above include tape and reel variants which are denoted with an "R" at the end of the orderable part numbers. The X denotes customizable part numbers.

This change is considered a minor change which does not affect form, fit, function, quality, or reliability. The information is being provided as a customer courtesy.

Please contact your local Silicon Labs sales representative with any questions about this notification. A list of Silicon Labs sales representatives may be found at www.silabs.com

Customer Actions Needed:

None